

# Work Order ID 109172

November-13-13 9:04:47 AM

**\*109172\***

Page 1

Item ID: D145-762-113GB Accept **\*N900040100\*** Setup Start **\*NS1\***  
 Revision ID: U/R Stop **\*NS2\***  
 Item Name: Skidtube W/ Run-On Landing Wearplates (Glossy Black)  
 Start Date: 11/13/13 Start Qty: 1.00 **\*1\*** Cust Item ID:  
 Required Date: 11/13/13 Req'd Qty: 1.00 **\*1\*** Customer:  
 Reference:

Approvals: Process Plan: *W* Date: Tooling: Date: Run Start **\*NR1\***  
 QC: Date: SPC (Y/N): Date: Stop **\*NR2\***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
<b>Draw Nbr</b>	<b>Revision Nbr</b>								
IIN-D117-762	<i># C A.P. 13.11.13</i>								
100	DOCUMENT CONTROL	0.00							
<b>*100*</b>									
DC	Memo <i>11.10.</i>	0.00							
Document Control	Photocopy bluefile & type labels per PPP D145-762-113 CHG001								
110	Pick Kit	0.00							
<b>*110*</b>									
Packaging	Memo	0.00							
Packaging									
120	QC4- 100% Inspect kits for completeness	0.00							
<b>*120*</b>									
QC	Memo	0.00							
Quality Control									

DAS  
16  
9-89

*13/11/13*

*13-11-13*

*002  
A.P.  
13.11.13*

*1X*

DAS  
28  
9-89

*13-10-30*

*(40)*

DAS  
16  
9-89

*13/11/13*

# Work Order ID 109172

November-13-13 9:04:47 AM

**\*109172\***

Page 2

Item ID:	D145-762-113GB	Accept	<b>*N900040100*</b>	Setup	Start	<b>*NS1*</b>
Revision ID:	U/R					
Item Name:	Skidtube W/ Run-On Landing Wearplates (Glossy Black)				Stop	<b>*NS2*</b>
Start Date:	11/13/13	Start Qty:	1.00	<b>*1*</b>	Cust Item ID:	
Required Date:	11/13/13	Req'd Qty:	1.00	<b>*1*</b>	Customer:	
Reference:						

Approvals:	Process Plan:	Date:	Tooling:	Date:	Run	Start	<b>*NR1*</b>
	QC:	Date:	SPC (Y/N):	Date:		Stop	<b>*NR2*</b>

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130	Packaging	0.00							
<b>*130*</b>									
Packaging	Memo	0.00			DAS				
Packaging	Identify and pack for shipping as per PPP D145-762-113				6				
	Location: <u>SHD</u>				9-59				
140	QC21- Final Inspection - Work Order Release	0.00							
<b>*140*</b>									
QC	Memo	0.00							
Quality Control									

ARC DONE BY  
DAA

11/13-11-19

pl 13-11-19

# Picklist Print

November-13-13 9:04:46 AM

Page 1

Work Order ID: 109172

Parent Item: D145-762-113GB

Parent Item Name: Skidtube W/ Run-On Landing Wearplates (Glossy Black)

Start Date: 11/13/13

Required Date: 11/13/13

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP REV:A 13.04.24 NEW ISSUE DD VERF:JLM

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D145-762-043		Manufactured	No			110	Each	0.0000	1				
Replacement Std Skidtube										B108936	DAS 28	13-10-30	
D145-762-153		Manufactured	No			110	Each	0.0000	1				
Replacement Run-On Landing Wearplates (Std Skidtube)										B108937	9-89 28	DAS 9-89	
AN6C51A		Purchased	No			110	Each	20.0000	2				
BOLT											DAS 28	9-89	
				<u>Location</u>		<u>Loc Qty</u>		<u>Loc Code</u>					
				ST341		20							
				126535		20							
D3864-1		Manufactured	No			110	Each	75.0000	4				
Bushing										2X	DAS 28	9-89	
				<u>Location</u>		<u>Loc Qty</u>		<u>Loc Code</u>					
				ST066		75							
				105297		40				4X			
				105463		31							
				99620		4							
MS21042L6		Purchased	No			110	Each	316.0000	2				
Nut											DAS 28	9-89	
				<u>Location</u>		<u>Loc Qty</u>		<u>Loc Code</u>					
				ST314		316							
				m126275		16				5X			
				m127304		300				127255			